

HDMI integrated splicing processor user's manual

V1.0

Use this manual:

This manual is suitable for splicing processors, thank you very much for purchasing our products, please read this manual carefully before using the equipment.

All the pictures in this manual are for reference only, please refer to the actual product.

The description in this manual may not correspond one-to-one to the product you purchased or your accessories. The Company reserves the right to modify any information in this manual at any time and will regularly improve or update the contents in this manual based on the enhancement of the product functionality. The updates will be included in the new version of this manual without notice.

catalogue

1. Safety instructions	6
2. The packing list	9
3. Get started quickly	9
3.1. Schematic diagram of the chassis connection	9
3.2. Communication interface description	10
4. Installation instructions	11
4.1. Connection schematic diagram	11
5. Web version control	13
5.1. The default value is the IP	13
5.2. How to obtain and modify the WEB card IP address	13
5.3. Visit the browser and enter the operation interface	14
5.3.1. Description of the software area	15
5.3.2. Signal bar	16
5.3.3. Function buttons	18
5.4. Modify the input of 2K and 4K mode	20
5.5. Window and signal operation	20
5.5.1. How to signal to open the window	20
5.5.2. How to switch the window signal	21
5.5.3., How to close the window	21
5.5.4. Modiof window size position	23
5.5.5. Window locking and logic filling	24
5.5.6. More operations	25
5.5.7. Plan operation	25
5.5.8. Change the name of the plan	26
5.5.9. Wheel patrol management	28

5.6., Equipment management	31
5.6.1. Splicing settings	31
5.6.2. The output management	31
5.6.3. Equipment management	32
5.6.4. Channel naming	32
5.6.5. Software Settings	33
5.6.6. How to change the user password	34
6. Central control protocol	35
6.1., Communication port	35
6.2. Switch over the input source instructions of the window .	35
6.3. Call the plan mode instruction	37
6.4., Test tool	38
7. Analysis and solution of common faults	39

1. Safety instructions

1.1. source

Please use the 220V AC power supply with single-phase three-wire system with protection ground, and ensure that the whole engineering system uses the same grounding, not the power supply without grounding protection, and the grounding foot of the power cord can not be destroyed.

1.2. interrupt

When the equipment moves or other situations requiring power off, turn off the power to ensure the safety of the equipment.

1.3. cable

It is not allowed to press items on power lines, signal lines, communication lines and other cables, and should avoid cable trampling and extrusion to prevent the occurrence of leakage and short circuit and other dangerous situations.

1.4. signal

Ensure that the signal line, communication line and other wires are well connected, and then start the operation.

1.5. heat radiation

The heat dissipation hole on the surface of the equipment should not be blocked, so as to avoid heat accumulation and damage to the equipment.

1.6. environment

The working environment of the equipment should pay attention to dustproof and moisture-proof to prevent liquid immersion.

1.7. keep in repair

All maintenance work should be completed by professional personnel, without permission, not allowed to avoid the danger of electric shock.

1.8. equipment installation

The equipment shall be installed on a stable and stable working surface or in a standard rack, cabinet and chassis.

1.9. Safety precautions

- 1) There is high pressure in the equipment, and non-professional maintenance personnel are not allowed to open the chassis to avoid danger.
- 2) Do not place containers with liquid on and near the equipment.
- 3) No equipment near the fire source.
- 4) Ensure adequate ventilation, and the front and rear panels of the equipment shall maintain at least a 20CM gap.
- 5) In the case of lightning or long-term not in use, please unplug the power plug.
- 6) Do not block the ventilation holes of the equipment to avoid causing damage to the equipment.
- 7) Do not place this device near the liquid.
- 8) Please place the power cord properly to prevent any damage.
- 9) In the following cases, unplug and leave it to a professional:
 - a) When the plug power cord is damaged or worn;
 - b) When the liquid is splashed into the equipment;
 - c) When the equipment falls or the chassis is damaged;
 - d) When the equipment has obvious abnormal function or performance change.

* Note: The equipment is not suitable for operation and debugging by non-professionals, and it must receive professional training or guidance. Please read this manual carefully before using this equipment. The manual should be properly kept for later use.

* Note: This is A Class A product that may cause radio interference in A living environment. In this case, users may need to take practical measures about their interference

注 1: 本设备为信息技术设备, 其无线电骚扰特性按 A 级信息技术设备要求。

警告

此为 A 级产品, 在生活环境中, 该产品可能会造成无线电干扰。在这种情况下, 可能需要用户对干扰采取切实可行的措施。


注 2. 本次申请产品内部产生或使用的最高频率, 或 EUT 工作或调谐的频率为: 2.0GHz, 本次申请辐射骚扰进行到 6GHz。

2. container loading list

project	name	quantity	unit
1	Splicing processor host	1	short for Taizhou
2	AC 220V National standard power cord	1	individual
3	Quick entry	1	stem or root of plants
4	parvicostellae	1	twig
5	Certificate warranty card	1	fix

3. Quick entry

3.1. A Schematic diagram of the chassis connection




joggle	explain	remarks
IP	10 / 100M Ethernet port	Default IP: 192.168.1.182

RS232 OUT	DB9 male head ring out of the control screen	
RS232 IN	DB9 head central control	Porter rate 1152000
AUDIO	The 3.5mm headphone port output	
HDMI IN	8 HDMI 1080P input, can be switched to 4K30 input	
HDMI OUT	8 channel HDMI output with 1920x1080@60Hz output	Specifications: 4-4,8-8,4-12

3.2. Communication interface description

Master control card



IP	IP network interface, switch / router, also directly connected to computer, web control
RS232 IN	RS232 interface, connect to the computer serial port
RS232 OUT	RS232 ring out, control the large screen
A-O joggle	Independent audio output port (audio of binding output channel 4)

Splice processor default IP: 192.168.1.182, port: 5000

Splice processor default serial port (RS232), baud rate: 115,200 bps;

● **The RJ 45 line order for RS232:**

foot position	definition	explain
2	TX	RS-232 protocol, sending data
3	RX	RS-232 protocol, received data
5	GND	Signal ground

4. installation instructions

4.1. Schematic diagram of the connection



5. Web version control


5.1. give tacit consent to IP

The default IP is 192.168.1.182

5.2. How to obtain and modify the WEB card IP address

5.2.1. Use the IPCTool tool to search for the WEB card IP addresses

Open IPCTool, click Auto Search, and the device version shows Web-CON-xxx for the device



IP 地址	设备型号	设备序列号	MAC 地址	版本信息
10.10.10.3	Web-CON-1.55.0...			
192.168.3.218	IR8			
192.168.100.32	Web-Splice-1.54...			
192.168.3.217	IRVT-HIS018ESIV...			
192.168.111.185	Web-Splice-1.47...			
192.168.3.208	IPC-model			
192.168.100.190	Web-CON-1.54.0...			
192.168.3.208	IPC2325-3034F4...	219802C011G175011081	48-EA-63-49-D8-68	IPC_G6103-R0006P2001705
192.168.3.209	IPC2325-3034F4...	219802C011G175018194	48-EA-63-4A-2C-0C	IPC_G6103-R0006P2001705
192.168.3.216	DS-2DC44200W-D			
192.168.3.201	DS-2CD4024F			
192.168.3.202	DS-2CD3345-I			
192.168.3.215	DS-2CD4024F			
192.168.3.219	DS-2CD3T100-I3			
192.168.10.21	Web-IP-1.1.0411			
192.168.10.154	Web-IP-1.1.0411			
192.168.10.24	Web-IP-1.1.0411			
192.168.10.111	Web-IP-1.1.0411			

IPCTool Download address: <http://www.smartrgb.com/upload/file/1647318930.zip>


5.2.2. Log in to the web page to modify the WEB card IP address

Enter the web page, enter the device management, the device network Settings can modify the WEB card IP address




5.3. Access the browser to enter the operating interface

Connect the terminal (mobile phone, computer or tablet) and the device to a LAN, open the browser access: 192.168.1.182, default user name: admin, password: admin, recommended Google browser




Note: Browsers that do not support the IE browser or the IE kernel


5.3.1. Software area description



1	Signal bar	Input signal list, webcam list
2	tool bar	New, empty, fast new, screen channel, open screen, close screen, more
3	Virtual screen wall	Window operation area
4	Plan column	Plan preview diagram, click switch plan
5	Screen switch	Multi-screen wall switching

5.3.2. Signal bar

<ol style="list-style-type: none">1. Show the total number of signals versus the number of signals2. Switch from the currently selected input signal to the window in the current screen3. Tree and list mode switching4. Input signal refresh5. The input has a signal in color and no signal is gray	 <p>The screenshot displays a user interface for signal management. On the left, a vertical list of input sources is shown: '小米盒子' (1), '2-HDMI' (2), '3-HDMI' (3), '4-HDMI' (4), and '5-IP4K' (5). Each item has a corresponding icon and a number in a blue circle. On the right, a panel titled '输入源 27/30' (Input Source 27/30) shows a tree view of signal cards: 'Card-01', 'Card-02', 'Card-03', 'Card-04', and 'Card-06'. The interface includes various icons for settings, refresh, and other functions.</p>
<ol style="list-style-type: none">6. Sliding description: If the signal number in the Pad exceeds the layout, you can slide the red area to adjust the layout	



5.3.3. Function button



new-built	Create a new window for the selected signal in the screen order
Quick construction	Quick window opening function Quickly create a split split window
one-for-one	Create a one-to-one new window according to the input signal source
empty	Empty the screen wall screen
Save the plan	Save the current screen into the preplan
synchronization	Synchronize data for the device
more	Switch / off screen (require device ring to connect screen 232 and protocol to match up)
Window lock	Lock the window of the current screen wall, move or close seamlessly, and switch the signal
The logic is full	Mouse slide open the window, according to the logical split screen dotted line automatically spread the window
more	Pair of all: switch the selected inputs to all windows

	Ring out control screen open / off screen
--	---

5.4. Modify the input 2K with the 4K mode

1. Right click select input mode, select 42K or 24K
2. Restart the device

5.5. Window and signal operation

5.5.1. How to signal the opening of a window


3. Drag the signal source to the blank area window



4. Click New, Quick New, or open a one to one window



5. Slide the mouse window in the blank area




5.5.2. How to switch the window signal

1. Drag the signal source to switch




2. Select the window and double-click the signal source switch




5.5.3. How to close the window

1. Click on the window's X



2. Drag the window to the outside of the screen wall



3. Click empty




4. Window right-click to close

5.5.4. Window size position modification

1. Move the window: click on the window to move the mouse to move the window position



2. Drag the window: Drag the 4 corners of the window to modify the window size




3. Edit coordinates: Right-click the window to edit the exact coordinates of the window



4. Window icon

They are: logical area full, whole screen full screen, closed window



5.5.5. Window locked and logical spread full

- Window lock: After the window is locked, the window cannot be dragged, and the window input signal source can be switched



- Logic full: open the logic full, will be the screen and the solid line for the unit of automatic full window



5.5.6. More operations


Ring out control large screen switch screen



5.5.7. Plan operation


- Save the plan

Click the plan box to be saved, and save it




- Loading plan

Click on the plan preview map or the plan serial number



5.5.8. Modify the name of the plan

Device management-> Channel naming-> Scene plan



- Delete the plan

Right click to delete or click the pop box to delete;



- Hide the plan bar



Note: The preview map and name of the plan saved by the client cannot be synchronized with the WEB terminal. Need to load the plan, click synchronization, and then save it

5.5.9. Round patrol management

指挥控制网络

系统控制

轮巡管理

设备管理

新建

删除

清空

全部启动

全部停止

查询

1

1

Scene-1

场景轮巡

摄像头:1
路: 1,2,3,4,5,6,7,8,9,10,11,12,13,14,15,16,1...

10s

关

未启动

启动

删除

清空

2

2

Scene-2

场景轮巡

摄像头:1
路: 1,2,3,4,5,6,7,8,9,10,11,12,13,14,15,16,1...

10s

关

未启动

启动

删除

清空

3

3

Decode-3

解码轮巡

摄像头:1,2,3,4,5,6,7,8,9,10,11,12,13,14,15
路: 1,2,3,4,5,6,7,8,9,10,11,12,13,14,15

30s

关

未启动

启动

删除

清空

4

4

Channel-4

通道轮巡

摄像头:1,2,3,4,5,6,7,8,9,10,11,12,13,14,15
路: 1,2,3,4,5,6,7,8,9,10,11,12,13,14,15

10s

关

未启动

启动

删除

清空

5

5

Decode-5

解码轮巡

摄像头:1,2,3,4,5,6,7,8,9,10,11,12,13,14,15
路: 1,2,3,4,5,6,7,8,9,10,11,12,13,14,15

10s

关

未启动

启动

删除

清空

1

2

- Menu function



New: new wheel patrol; delete: delete the currently selected round patrol; empty:
empty the wheel patrol data;

Start: start all patrol data; stop: stop all patrol data

- Scene round patrol

The saved scene is selected for the cycle switching display

轮盘任务 - 新建

轮盘架型

☒ 标准轮盘
 ☐ 通盘轮盘
 ☐ 解码轮盘
 ☐ 自定义轮盘

轮盘名称

Scene-6

开机自启

☒ 是
 ☐ 否

模式

排舞模式

屏基

☒ 屏基值1
 ☐ 屏基值2

修改间隔

修改间隔

确定

协议列表

<input type="checkbox"/>	标签	间隔(秒)	操作
<input type="checkbox"/>	全屏模式	10	□
<input type="checkbox"/>	分屏模式	10	□
<input type="checkbox"/>	分屏模式	10	□
<input type="checkbox"/>	分屏模式	10	□
<input type="checkbox"/>	分屏模式	10	□

取消

确定

- Wheel patrol type: scene wheel patrol
- Round patrol name
- Start automatically
- Mode: Mosaic mode / matrix mode
- Screen wall
- Batch modification interval time
- Add the scene

Channel round patrol

The selected input switches in an output (window)

轮巡任务 - 新建

轮巡类型: ☐ 场景轮巡 ☒ 通巡轮巡 ☐ 解码轮巡 ☐ 自定义轮巡

轮巡名称:

开机自启: ☒

模式:

屏显地: ☒ 屏显地1 ☐ 屏显地2

输出通道:

修改间隔:

协议列表		新建	删除
<input type="checkbox"/>	输入	间隔	操作
<input type="checkbox"/>	小样盒子1	10	
<input type="checkbox"/>	2-HDMI	10	
<input type="checkbox"/>	3-HDMI	10	
<input type="checkbox"/>	4-HDMI	10	
<input type="checkbox"/>	5-IPKVC	10	

- Wheel patrol type: channel wheel patrol
- Round patrol name
- Boot up and start up
- Mode: Mosaic mode / matrix mode
- Screen wall
- Window requiring wheel patrol (the corresponding window of the output)
- Batch modification interval time
- Add input source

Custom wheel patrol

Follow up the central control agreement, customize the round patrol agreement, can support the third party round patrol equipment

轮巡任务 - 新建

轮巡类型

☐ 场景轮巡 ☐ 通播轮巡 ☐ 解码轮巡 ☒ 自定义轮巡

轮巡名称

Custom-6

开机自启

☐

环出选择

☒

波特率

9600

修改间隔

修改间隔

确定

协议列表

☐

协议

间隔

说明

Hex

操作

☐

10

☒

☐

10

☒

☐

10

☒

取消

保存

- function declaration
- Wheel patrol type: custom wheel patrol
 - Round patrol name
 - Ring out selection (whether to control the third party device)
 - Ring-out port rate selection
 - Batch modification interval time
 - Add a custom wheel patrol protocol

Note: If this function is required to use, it is recommended for users with integrated development capability

5.6. device management

5.6.1. Split setting



Screen wall configuration: screen wall name, logical split screen, screen background color

Screen configuration: splicing specifications


5.6.2. Output management



1. Click to empty the output or drag the screen wall out of the screen wall
2. Double-click on the left output channel,

3. Look at the big screen. which screen has a black white cross
4. Drag the output channel to the corresponding screen

5.6.3. device management

<ul style="list-style-type: none"> ● The buzzer switch ● unit type ● WEB board Web Settings ● Ring-out splicing protocol setting ● Board card version query ● Master dashboard network settings 	
---	---

5.6.4. Channel naming


Custom input, output, plan name

5.6.5. Software Settings

- Set the language
- Theme color setting
- Software Background Color Settings (virtual screen wall)
- Software name modification
- WEB software release
- UI software release
- Software function switch
- Software logo settings

5.6.6. How to modify the user password

1. Click on the user icon



2. Enter a new password

A screenshot of a '修改密码' (Change Password) dialog box. The dialog has a title bar with the text '修改密码' and a close button (X). It contains three input fields: '旧密码' (Old Password) with the placeholder '请输入旧密码', '新密码' (New Password) with the placeholder '请输入新密码', and '确认密码' (Confirm Password) with the placeholder '请确认新密码'. At the bottom right, there are two buttons: '取消' (Cancel) and '保存' (Save).

6. Central control agreement

6.1. communication port

- Serial port configuration, and port rate: 115200bps; communication format: 1 bit start bit, 8 bit data bit, 1 bit stop bit, no check
- Network port configuration, ports: 5000,5100,5200,5300
- The protocol format is ASCII. If the central control only supports 166, it can be converted to 16 through the tool

6.2. Switch over the input source instructions of the window

instruction format	<switch,wall_id ,win_id ,src_id ,src_x ,src_y ,src_w ,src_h >		
Directive definition	This instruction indicates that the content of a window is the specified input source		
protocol specification	form	explain	remarks
	<	Protocol Start	fixed value
	switch	Agreement instruction	Fixed protocol value
	wall_id	Screen wall ID	From 0, with a maximum of 3
	win_id	window ID	From 0, with a maximum of 255
	src_id	signal source ID	From 1, with a maximum of 144


	src_id ,src_x ,src_y ,src_w ,src_h	Signal cropping size	Default values are 0,0,0,0
	>	Protocol end	fixed value
returned value	<switch cmd done>		
Refer to the agreement	Refer to the agreement	explain	
	<switch,0,0,3,0,0,0,0>	Wall 1, the signal source of the window	
	<switch,0,1,3,0,0,0,0>	Wall 1, the signal source of the window	
	<switch,1,3,1,0,0,0,0>	Wall 2, the signal source of the window	

6.3. Call the plan mode command

instruction format	<call,Wall_ID,Scene_id>		
Directive definition	This instruction indicates the scenario mode where the specified screen group calls the saved specified number.		
protocol specification	form	explain	remarks
	<	Protocol Start	fixed value
	call	Agreement instruction	Fixed protocol value
	Wall_ID	Screen wall ID	From 0, with a maximum of 3
	Scene_id	plan ID	From 1, with a maximum of 32
	>	Protocol end	fixed value
returned value	<call cmd done>		
Refer to the command	<p>[Example 1] <call, 0,1></p> <p>It means that the no. 1 plan mode of the first group display wall is retrieved. The saving and deletion of the plan scene should be saved in advance through the client software.</p>		

Note: The default mode is 1 for all, or all outputs show 1 input

6.4. test tools



- Conversion tool (string 16)

<https://www.asciitohex.com/>

7. Common fault analysis and resolution

7.1. Cannot run after software

Possible reasons: The customer computer lacks the relevant software running support component (Microsoft.NET. Exe); being blocked or deleted by anti-virus software;

resolvent: Enter the software installation directory, in the Tool folder, install. Net40. Temporary close antivirus software or computer butler, or add the program to the computer butler exception.

7.2. Unable to search or connect to the device

Possible reasons: No network or serial port; the IP address conflicts with other devices on the LAN; a network card in a LAN with the device is not selected

resolvent: Using the command prompt, the IP of the Ping device will check whether the network is connected; modify the IP address to reconnect; and re-select the computer network card

7.3. The output picture shows no reason

Possible reasons: No signal input; output line damage or beyond transmission distance; output mapping is not configured correctly.

resolvent: Check the input signal, confirm that the input signal channel is normal, check whether the LED indicator of the port is on; confirm that OUT is the output device and IN is connected to the input device;

7.4. The reason for the color deviation phenomenon of the picture

Possible reasons: The interface is not properly connected, resulting to poor contact; the signal cable is damaged; the color adjustment of the display equipment is incorrect; incorrect color adjustment using the software.

resolvent: 1) After the interface is connected, tighten the bolts to prevent loosening due by pulling;
2) Adjust the color balance of the display equipment according to the operation manual of the display equipment;

7.5. The picture shakes or flower points

Possible reasons: Too long cable causes serious signal loss; the equipment of the input signal is unstable or the wire is damaged.

resolvent: It is recommended to use signal extender to ensure minimum line loss; debug the function definition of input signal and use high quality wire.

7.6. The screen is not complete in the display device

Possible reasons: Your display has a back-end removal of the signal; you adjust the image too much with the control software

resolvent: Follow the instructions for the display device, adjust the default settings in the software; control the software, readjust the position of the image to achieve the effect you need.

7.7. The picture splicing shows the dislocation

Possible reasons: The screen is spliced, and the output map does not match the physical cable

resolvent: Turn the screen to single screen mode; check the setting output mapping



Instructions to update the QR code

Thanks for the use of our company